## Schwinn IC4: Noises from the belt area

ID: 13907.1

Follow this troubleshooting guide to help resolve noise issues on the Schwinn IC4 indoor cycling bike.

### Some common complaints may include:

- Grinding noises
- Squeaking noises
- Rubbing noises

### Follow these steps to troubleshoot the issue

Tools you may need:

Regular flathead screwdriver

Phillips head screwdriver

25mm Crank Puller (if removing crank arms to troubleshoot)

15mm, 16mm socket wrench

10mm, 15mm wrench

3.5mm, 5mm hex/Allen wrench

- 1. Remove the crank arm cap and tighten the crank nuts on both crank arms using a socket wrench [13907.A].
- 2. Using a 25mm Crank Puller, remove the right crank arm and the outer belt cover.
- 3. Inspect the belt for damage or areas where it may be rubbing. If the belt is damaged, order a Drive Belt [13907.B].
  - Important: in order to replace the drive belt, a 25mm Crank Puller will be required to remove the crank arms and
    access the belt. Order a 25mm Crank Puller in addition to the belt unless you have one already.
- 4. If the belt is rubbing, please refer to the "Adjust the Drive Belt" section of your <u>service manual</u> to adjust the position of the flywheel [13907.C]. If you need additional assistance with the adjustment, please contact Customer Care. Our contact information is listed at the bottom of this page

#### **Need to order replacement parts?**

### 1 Customer Care Contact Information

Please contact Customer Care at 1-800-605-3369 for additional help or to order replacement parts. Some replacement parts may also be available for purchase <u>online here</u>.

A list of part numbers referenced within this guide can be located at the bottom of this page.

#### **Customer Care - Hours of Operation:**

Monday - Friday 6:00am - 5:00pm PST

The replacement part will be provided to you at no cost assuming your machine meets the warranty eligibility requirements. A Customer Care Agent will be able to assess your current warranty eligibility and provide you with your options.

about:blank 1/2

Please note that if you did not purchase your machine directly from BowFlex, Schwinn, or Nautilus, we will need a copy of your purchase receipt in order to register your machine for warranty.

## 2 Parts Reference Table

Part Description	Part SKU
25mm Crank Puller	8018316
Drive Belt	8022657

# 3 Contact Tech Team / Advanced Troubleshooting

If the issue was not resolved in the steps listed, contact the Tech Team or send an Advanced Troubleshooting case.

Submit a Case with case type Advanced Troubleshooting

about:blank 2/2